

OIL INFORMATION OF CNC MILLING MACHINE

Item	Name	Capacity	Oil Number	Oil Brand	Maintenance
Air filter	Lubrication	125ML	NO.32	Mobile DTE OIL LIGHT Shell TONNA T32	Less than 2/3 of the oil cup needs to be input.
Hydraulic pump	Anti-wear hydraulic oil	40L	NO.24 NO.32	Mobile DTE24 Shell Tellus No.32	3months after the 1st use, and then every 6month needs to be replaced.
Spindle Oil Coolant	Coolant oil	20L	No.32	Mobile VELOCITE OIL NO.10 Shell TONNA T32	Every 3month
Lubrication oil	Guide way oil	2L	No.68	Mobile VACTRA NO.2 ISOG68 Shell TONNA T68	Lower than the leveler needs to be input.
Cylindrical	Lubrication Oil	130ML	No.24 No.32	Mobile DTE24 Shell Tellus Anti-wear hydraulic oil No.32	Less than 1/3 cup needs to be input.
Rotary table	Lubrication oil	5L	NO.100	Shell Tonna No.100	Every 3 month